

## Scalar i3, i6, and i6H Release Notes 340G.GS153

Original Product/Software Release Date October 2025

#### Contents

About This Release	2
General Information	2
Security Scanners	5
Compatibility and Support	5
Resolved Issues	11
Known Issues	12
Documentation	15
Contacting Quantum Support	17

© 2025 Quantum Corporation. All rights reserved. Your right to copy this manual is limited by copyright law. Making copies or adaptations without prior written authorization of Quantum Corporation is prohibited by law and constitutes a punishable violation of the law. ActiveScale, DXi, DXi Accent, FlexSync, FlexTier, iLayer, Lattus, Myriad, Quantum, the Quantum logo, QXS, Scalar, StorNext, SuperLoader, Unified Surveillance Platform, USP, Vision, and Xcellis are either registered trademarks or trademarks of Quantum Corporation and its affiliates in the United States and/or other countries. All other trademarks are the property of their respective owners. Quantum specifications are subject to change.

November 2025 6-68531-44 RevB

## **About This Release**

The Scalar 340G.GS153 release is a feature and maintenance release that details bug fixes described in the Resolved Issues section. Refer to Known Issues for additional information.

#### Important Information - Firmware Upgrade Time and Thales KMIP Server

- The 340 library firmware upgrade includes a database migration. Depending on the amount of data on the library, this firmware upgrade may take up to 2 hours to successfully complete.
- If you are using a Thales KMIP server, do not upgrade to 340 library firmware.

#### What's New in this Release?

This release supports the Scalar i3, i6, and i6H libraries. Enhancements in this library include:

- LTO-10 full-height drive support (Scalar i6)
- · IBM SKLM (KMIP) key set enhancements.
- · Library drive firmware updates.
- To view all bug fixes and enhancements, see Resolved Issues on page 11

### General Information

- The Product library WebGUI application requires that the browser cache be cleared and the application re-loaded to ensure that all new functionality is implemented.
- (Scalar i3/i6 only) If an iBlade is present, Scalar systems with an Internet connection will automatically
  update and level the iBlade BaseOS FW during a library FW update.

If the Scalar system does not have an Internet connection, you can still update your iBlade BaseOS FW as described on our Documentation Center:

- Go to <u>www.quantum.com/documentation</u> and select your product.
- Go to Operate > User Guide > About Devices > Devices BaseOS. To will see detailed steps on updating iBlade BaseOS FW
- (Scalar i3/i6 only) Veeam Tape Server iBlades If Microsoft Hyper-V or any other hypervisor is
  installed on the Veeam Tape Server iBlade, the Virtual Machine (VM) Operating System (OS) will not
  be able to see the blade FC/SAS controller. This will cause the Scalar drives to no longer be visible to
  the VM OS.

- (Scalar i3/i6 only) Bridging and teaming interfaces on the Veeam Tape Server iBlade is not supported and can cause network card issues.
- Some snapshots, logs or RAS tickets are as large as 12 MBs. If you have automated notifications
  configured for RAS tickets and logs you may not receive them if your email does not allow attachments
  of this size.
- The Web client places a cookie on the user's computer to provide the last user's credentials upon login. The cookie only collects the user's credentials to facilitate login, and does not collect any other user data.
- Any application or browser connecting over https must support TLS v1.2 or higher.
- To help maintain system integrity and for marketing purposes, Quantum regularly collects system
  information through automatic emails and cloud based telemetric auto support. These emails and auto
  support telemetric data contain configuration and status information only, and do not contain any
  customer data stored on the system.

#### **Email Support**

To disable this function:

- 1. Log on to your library.
- 2. Select Notifications from the Navigation menu.
- 3. Select the check box next to scalartelemetrics@guantum.com in the North Panel.
- 4. From the **Operation** panel, select **Reports**.
- 5. Click the trash can icon next to **Scalar Telemetrics** report.
- 6. Click Apply, then Close.

#### **Auto Support**

To disable this function:

- 1. Log on to your library.
- 2. Select **Notifications** from the **Navigation** menu.
- 3. Select the check box next to Auto Support in the North Panel.
- 4. To disable RAS tickets, select **RAS Tickets** From the **Operation** panel.
- 5. De-select the Enable Auto Support Communication check box.
- Click Apply, then Close.
- 7. From the **Operation** panel, select **Reports**.
- 8. Click the trash can icon next to **Scalar Telemetrics** report.
- 9. Click Apply, then Close.

After a library firmware upgrade, Quantum recommends that you clear your web browser cache before logging back into the WebGUI.

## **Library Default Settings**

Scalar i3, i6, and i6H software is installed with certain default settings. This section outlines those default settings. Review this section to determine if any of the default settings need to be changed to make your library run more effectively.

User Access > Settings     Local User Interface (LUI) Access     Open Access       Admin/User Access: Session Timeout     15 minutes       Brable Local Service Access: Enable Remote Access     Disabled       Indefinite     Enable Local Service Port Login: Access     Indefinite       Notifications > RAS Tickets     Enabled RAS Tickets     Enabled       Notifications > Reports     Severity     All options Enabled       Notifications > Reports     Once you have an email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.     Once you have an email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.       Library > IE Area     I/E Slots     0 (zero)       Library > Settings     Operational Parameters: Automatic Inventory     Enabled       Depeational Parameters: Library Assisted Disabled Drive Unload     Disabled       Operational Parameters: Logical Drive Serial Number Addressing     Enabled       Depeational Parameters: Logical System Addressing     Disabled       IE Assignment Mode: Local UI Assignment     Enabled       System > Notifications     Email Reports / Auto Support     Enabled       System > Settings     Library-Initiated Website Access     Enabled	WebGUI Path	Option	Default Setting
Services Access: Enable Remote Access Disabled Enable Local Service Port Login: Access Window  Notifications > RAS Tickets Enable RAS Tickets Enabled Severity All options Enabled  Notifications > Reports Scalar Telemetrics Once you have an email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.  Library > IE Area I/E Slots Operational Parameters: Automatic Inventory  Disabled Drive Unload Operational Parameters: Library Assisted Disabled Drive Unload Operational Parameters: Logical Drive Serial Number Addressing Disabled Addressing IE Assignment Mode: Local UI Assignment Enabled System > Network Email Reports / Auto Support Enabled Enabled	User Access > Settings	Local User Interface (LUI) Access	Open Access
Enable Local Service Port Login: Access Window		Admin/User Access: Session Timeout	15 minutes
Notifications > RAS Tickets       Enable RAS Tickets       Enabled         Notifications > Reports       Sceverity       All options Enabled         Notifications > Reports       Scalar Telemetrics       Once you have an email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.         Library > IE Area       I/E Slots       0 (zero)         Library > Settings       Operational Parameters: Automatic Inventory       Enabled         Operational Parameters: Library Assisted Drive Unload       Disabled         Operational Parameters: Logical Drive Serial Number Addressing       Enabled         Operational Parameters: Logical System Addressing       Disabled         IE Assignment Mode: Local UI Assignment       Enabled         System > Network       Connectivity / SSH       Disabled         System > Notifications       Email Reports / Auto Support       Enabled		Services Access: Enable Remote Access	Disabled
Notifications > Reports       Scalar Telemetrics       Once you have an email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.         Library > IE Area       I/E Slots       0 (zero)         Library > Settings       Operational Parameters: Automatic Inventory       Enabled         Operational Parameters: Library Assisted Drive Unload       Disabled         Operational Parameters: Logical Drive Serial Number Addressing       Enabled         Operational Parameters: Logical System Addressing       Disabled         UE Assignment Mode: Local UI Assignment       Enabled         System > Network       Connectivity / SSH       Disabled         System > Notifications       Email Reports / Auto Support       Enabled		_	Indefinite
Notifications > Reports  Scalar Telemetrics  Once you have an email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.  Library > IE Area  I/E Slots  Operational Parameters: Automatic Inventory  Operational Parameters: Library Assisted Disabled  Drive Unload  Operational Parameters: Logical Drive Serial Number Addressing  Operational Parameters: Logical System Addressing  IE Assignment Mode: Local UI Assignment  Enabled  System > Network  Connectivity / SSH  Disabled  System > Notifications  Enabled	Notifications > RAS Tickets	Enable RAS Tickets	Enabled
email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the Trash icon.  Library > IE Area		Severity	All options Enabled
Library > Settings       Operational Parameters: Automatic Inventory       Enabled         Operational Parameters: Library Assisted Drive Unload       Disabled         Operational Parameters: Logical Drive Serial Number Addressing       Enabled         Operational Parameters: Logical System Addressing       Disabled         IE Assignment Mode: Local UI Assignment       Enabled         System > Network       Connectivity / SSH       Disabled         System > Notifications       Email Reports / Auto Support       Enabled	Notifications > Reports	Scalar Telemetrics	email server configured, telemetrics is enabled for monthly automatic emails. To disable, click the
Inventory  Operational Parameters: Library Assisted Disabled Drive Unload  Operational Parameters: Logical Drive Serial Number Addressing  Operational Parameters: Logical System Addressing  Operational Parameters: Logical System Disabled Addressing  IE Assignment Mode: Local UI Assignment Enabled  System > Network  Connectivity / SSH  Disabled  System > Notifications  Email Reports / Auto Support  Enabled	Library > IE Area	I/E Slots	0 (zero)
Drive Unload  Operational Parameters: Logical Drive Serial Number Addressing  Operational Parameters: Logical System Addressing  Disabled  IE Assignment Mode: Local UI Assignment Enabled  System > Network  Connectivity / SSH  Disabled  System > Notifications  Email Reports / Auto Support  Enabled	Library > Settings		Enabled
Serial Number Addressing  Operational Parameters: Logical System Addressing  IE Assignment Mode: Local UI Assignment Enabled  System > Network  Connectivity / SSH  Disabled  System > Notifications  Email Reports / Auto Support  Enabled		•	Disabled
Addressing  IE Assignment Mode: Local UI Assignment Enabled  System > Network Connectivity / SSH Disabled  System > Notifications Email Reports / Auto Support Enabled		•	Enabled
System > Network Connectivity / SSH Disabled  System > Notifications Email Reports / Auto Support Enabled		,	Disabled
System > Notifications Email Reports / Auto Support Enabled		IE Assignment Mode: Local UI Assignment	Enabled
	System > Network	Connectivity / SSH	Disabled
System > Settings Library-Initiated Website Access Enabled	System > Notifications	Email Reports / Auto Support	Enabled
	System > Settings	Library-Initiated Website Access	Enabled

# **Security Scanners**

Quantum tests with the following Security scanners against the library:

Tenable Nessus Professional Version 10 - Version: 10.9.2 (#17) WINDOWS

No high/critical vulnerabilities found against this release using Nessus Professional Security Scanner.

# Compatibility and Support

## **Encryption Key Management Drive Support**

The following table provides the encryption key management drive support.

#### **Full-Height Drives**

Encryption Option	IBM LTO-6	IBM LTO-7	IBM LTO-8	IBM LTO-9	IBM LTO-10
	(FH)	(FH)	(FH)	(FH)	(FH)
Application Managed Encryption	Supported	Supported	Supported	Supported	Supported
SKM	Requires	Requires	Requires	Requires	Requires
	SKM License				
IBM SKLM (KMIP) <sup>2</sup>	Requires	Requires	Requires	Requires	Requires
	EKM License				
KMIP Key Manager <sup>1</sup>	Requires	Requires	Requires	Requires	Requires
	EKM License				

<sup>1.</sup> Only SafeNet/Thales encryption key servers are supported/tested KMIP configurations.

<sup>2.</sup> Applies to IBM SKLM and GKLM key server communication using the KMIP communication protocol.

### Half-Height Drives

Encryption Option	IBM LTO-6 (HH)	IBM LTO-7 (HH)	IBM LTO-8 (HH)	IBM LTO-9 (HH)
Application Managed Encryption	Supported	Supported	Supported	Supported
SKM	Requires SKM	Requires SKM	Requires SKM	Requires SKM
	License	License	License	License
IBM SKLM (KMIP) <sup>2</sup>	Requires EKM	Requires EKM	Requires EKM	Requires EKM
	License	License	License	License
KMIP Key Manager <sup>1</sup>	Requires EKM	Requires EKM	Requires EKM	Requires EKM
	License	License	License	License

<sup>1.</sup> Only SafeNet/Thales encryption key servers are supported/tested KMIP configurations.

## Web Browser Support

The Scalar i3, i6, and i6H WebGUI supports the following web browsers. Quantum recommends upgrading to the latest version of the browser.

Web Browser	Versions Supported
Internet Explorer	Not supported.
Google Chrome	Recommend latest version.
Mozilla Firefox	Recommend latest version.
Apple Safari	Recommend latest version.
Microsoft Edge	Recommend latest version.

<sup>2.</sup> Applies to IBM SKLM and GKLM key server communication using the KMIP communication protocol.

## Firmware Compatibility

For the most up-to-date information on the latest qualified library and drive firmware, please visit:

#### Scalar i3 Firmware

https://www.quantum.com/en/service-support/downloads-and-firmware/si3/

#### Scalar i6 Firmware

https://www.quantum.com/en/service-support/downloads-and-firmware/si6/

## **Drive Firmware**

### Scalar i3 Drives

SAS Half High (HH) Drive Types	Latest Firmware Version
IBM LTO-6 (SAS) (HH) 6 Gb	KAJ9¹
IBM LTO-7 (SAS) (HH) 6 Gb	S2T1 <sup>1</sup>
IBM LTO-8 (SAS) (HH) 6 Gb	S2T1 <sup>1</sup>
IBM LTO-9 (SAS) (HH) 12 Gb	S2S1 <sup>1</sup>
<sup>1</sup> Bundled with library firmware.	

FC Half High (HH) Drive Types	Latest Firmware Version
IBM LTO 6 (EC) (HH) 9 Ch	KAJ9 (Standard)¹
IBM LTO-6 (FC) (HH) 8 Gb	KAJ9 (FIPS)
IBM LTO 7 (EC) (HH) 9 Ch	S2T1 (Standard)¹
IBM LTO-7 (FC) (HH) 8 Gb	S2T1 (FIPS)
IDM LTO 9 (FC) (HU) 9 Ch	S2T1 (Standard) ¹
IBM LTO-8 (FC) (HH) 8 Gb	S2T1 (FIPS)
IBM LTO 0 /FC) /HU) 9 Ch	S2S1 (Standard)¹
IBM LTO-9 (FC) (HH) 8 Gb	S2S1 (FIPS)
<sup>1</sup> Bundled with library firmware.	

### Scalar i6 Drives

FC Full High (FH) Drive Types	Latest Firmware Version
IBM LTO-6 (FC) (FH) 8 Gb	KAJ8 (Standard)¹
	KAJ8 (FIPS)
IBM LTO-7 (FC) (FH) 8 Gb <sup>1</sup>	S2T0 (Standard)¹
	S2T0 (FIPS)

FC Full High (FH) Drive Types	Latest Firmware Version
IBM LTO-8 (FC) (FH) 8 Gb	S2T0 (Standard)¹
IBM E10-6 (FC) (F11) 6 GB	S2T0 (FIPS)
IDM LTO 0 (FC) (FU) 9 Ch	S2S0 (Standard)¹
IBM LTO-9 (FC) (FH) 8 Gb	S2S0 (FIPS)
IDM LTO 0 (CAS) (FU) 12 Ch1	S2S0 (Standard)¹
IBM LTO-9 (SAS) (FH) 12 Gb <sup>1</sup>	S2S0 (FIPS)
IBM LTO-10 (FC) (FH) 32 Gb	S57A (Standard)¹
IBM E10-10 (FC) (FH) 32 GD	S57A (FIPS)
IBM LTO-10 (SAS) (FH) 12 Gb	S57A (Standard)¹
IDIVI LTO-10 (3A3) (FT) 12 GD	S57A (FIPS)
<sup>1</sup> Bundled with library firmware.	

### Scalar i6H Drives

FC Full High (FH) Drive Types	Latest Firmware Version
IBM LTO-7 (FC) (FH) 8 Gb	S2T0 (Standard)¹
IBM E10-7 (FC) (FH) 8 GB	S2T0 (FIPS)
IBM LTO-8 (FC) (FH) 8 Gb	S2T0 (Standard)¹
IBM E10-6 (FC) (F11) 6 GB	S2T0 (FIPS)
IBM LTO-9 (FC) (FH) 8 Gb	S2S0 (Standard)¹
IBM L10-9 (гс) (гп) о Gb	S2S0 (FIPS)
IBM LTO-9 (SAS) (FH) 12 Gb	S2S0 (Standard)¹
IBM L10-9 (3A3) (FH) 12 GD	S2S0 (FIPS)
<sup>1</sup> Bundled with library firmware.	

## iBlade BaseOS Versions for Library Code

The following table provides the iBlade BaseOS versions for the 340G.GS153 library code.

iBlade OS	Customer BaseOS Download From Web	iBlade SLFTS Application
Linux	1.3.0-6	2.10.0-40
Windows	1.3.0-4	N/A

The latest tape driver versions are located at:

#### Scalar i3

https://www.quantum.com/en/service-support/downloads-and-firmware/si3/

#### Scalar i6

https://www.quantum.com/en/service-support/downloads-and-firmware/si6/

# Resolved Issues

Change Request Number	Customer Case Number	Description	Resolution
SQ-3077		Library WebGUI does not display the correct active KMIP server.	Fixed.
SQ-3495		Library user role and configured entitlement should have access to Media LTO-9 calibration.	Fixed.
SQ-3512		Allow the library user role to perform all maintenance and action operations for drives based on user entitlement.	Enhancement.
SQ-3513	829611	Library user role and configured entitlement should have access to Media EDLM Test and EDLM Sessions operations.	Fixed.
SQ-3906		IBM SKLM (KMIP) key set Web Services API enhancements.	Enhancement.
SQ-3986		Library drive firmware upgrade for LTO-7 (S2T0/1), LTO-8 (S2T0/1), and LTO-9 (S2S0/1)	Enhancement.
SQ-3993		IBM SKLM (KMIP) allows incorrect SKPP and SKPL selections when key sets exist	Fixed.
SQ-4008		Updated online help bundles.	Enhancement.
WUI-2062		Cannot disable a partition's Library Managed Encryption (LME) if an IBM SKLM (KMIP) key set is not ready.	Fixed.
WUI-2239			
WUI-2037	00823196	IBM SKLM (KMIP) key set WebGUI improvements.	Enhancement.
SQ-3782			
WUI-2250		Cleaning Slot cleaning-eligible storage calculation issue.	Fixed.

# **Known Issues**

This release of Product 340G.GS153 firmware has the following known issues:

Change Request Number	Description	Workaround
SQ-556	Veeam iBlade updates fail when using service port.	Use customer port to perform Veeam iBlade updates.
SQ-1193	Manual drive cleaning fails when I/E station is open and closed while cleaning is in process.	Close error and repeat manual drive cleaning.
SQ-1531	Humidity and temperature differences occur between the library temperature and humidity sensors and additional sensors outside of the library.	Library temperature and humidity readings may be different than additional temperature and humidity readings within a data center. Temperature and humidity sensors provide status for temperature readings and approximations internal to the library enclosure.
		External air outside is heated up inside the library enclosure due to numerous factors, such as the frequency of robotic operations and the number of drives and drive operations. This can warm the air by about 2°C to 6°C within the library enclosure.
		As result of the air heating inside the library, the humidity will also drop within the library enclosure. Keep this in mind when setting library temperature and humidity ranges.
SQ-1585	Drive sled connectivity issues generate RAS ticket ET085 (Drive Sled Connection Problem).	There is no workaround, but the occurrence of this error will be greatly reduced in the latest 320 library firmware release.
SQ-1733	A syslog resource with an invalid name is created when DNS is configured. When running a test command, the response is 500, The syslog server test failed.	Make sure the configured syslog server can be reached with DNS identification.
	This can be incorrectly interpreted that the test started but was not finished successfully, when the issue is that the host does not exist.	

Change Request Number	Description	Workaround
SQ-2711	Attempting to upgrade library firmware to a newer firmware version from the "Firmware from Quantum Website" upload option under System > Library Firmware fails.	Download the firmware to your local computer and use the "Firmware from Local Computer" upload option.
SQ-3163	If the "Automatic Install on Next Reboot" library firmware upgrade option is selected, the "Roll back to firmware/firmware version" radio button does not display the previous version of library firmware after the firmware upgrade is complete.	Previous versions of library firmware can be uploaded to the library using the "Firmware from Local Computer" upgrade option.
SQ-3322	WebGUI issues occur when using browser tabs to sign in as two different users in the same browser.	Do not sign on as two different users within the same browser. You MUST sign off in order to log in as a different user; or use a different browser.
SQ-3324	Drive link status may be down upon library boot after library reset.	Disregard status. Drive are operational during a reset.
SQ-3487	A LTO-9 tape from an air gap magazine slot is logically blocked after being calibrated.	Unblock media tape in air gap magazine.
SQ-3588	Drive status of a drive performing LTO-9 calibration operations displays "Good" instead of "Calibrating".	Drive status should change to "Calibrating" after 30 seconds of calibration operations.
SQ-3742	Performance Summary window in the Drive WebGUI topic fails to display data for Read/Write or Mount Counts until the tape is unloaded.	Drive performance data applies to any operations having completed and dismounted from drives. The data does note include data currently in progress by mounted drives.
SQ-3752	Cleaning Window dialog box Use Count value does not match value seen in Drive Cleaning report.	The Drive Cleaning report contains the accurate use count value.
SQ-3827	When attempting to enable the PIN Required option in User Access Settings dialog with a previously used PIN, an error occurs that states "Unable to update password. Previous password can not be used".	Enter a PIN number that is different from the previously used PIN number.
SQ-3876	Air gap "Sequester on Full" tape count field is not reset back to the default number of tape slots in a magazine when it is removed from a partition.	Manually reset the tape count to the default value.

Change Request Number	Description	Workaround
WUI-1273	Drive/Media Issue Timeline does not show all data for selected time frame.	Select larger time frame.
WUI-1493	System > Syslog and Encryption > KMIP Key Manager modal windows display 11th row.	Disregard 11th row. Only 10 servers (10 row entries) are allowed.
WUI-1709	Drive connection details do not show the actual port configuration, but show requested drive settings.	Check switch or host information to determine actual connection speed or topology.
WUI-1807	After library is reset to factory default, the WebGUI displays an unknown product error message.	If you receive this error, refresh the WebGUI page and re-install current code.
WUI-1849	Library humidity and temperature min/max values do not update when using the slider.	Enter the updated range in Min (%) and Max (%) fields. Select <b>Apply</b> to update the range.
WUI-2006	LDAP - Enable Kerberos does not occur if the Kerberos configuration was previously enabled and disabled.	Disable and re-enable LDAP.


## **Documentation**

### Scalar i3 Documentation

All Scalar i3 documentation is available at the Scalar i3 Documentation Center: www.quantum.com/Scalari3Docs

Scalar i3 documentation includes:

- · Site Planning Guide
- · Installation Guide
- · Operation Guides
- · Repair and Upgrade Guides
- Reference Guides (Web Services, SCSI, SNMP)




### Scalar i6 Documentation

All Scalar i6 documentation is available at the Scalar i6 Documentation Center: www.quantum.com/Scalari6Docs

Scalar i6 documentation includes:

- · Site Planning Guide
- · Installation Guide
- Operation Guides (WebGUI, SNMP, SCSI, Web Services)
- Repair and Upgrade Guides
- · Reference Guides



## **Contacting Quantum Support**

Below is information related to contacting Quantum Support as well as steps to improve your Quantum customer journey.

- Chatbot below
- · Open a Service Case below
- Use MyQuantum Service Delivery Platform on the next page
- Use Cloud Based Analytics (CBA) on the next page
- Escalate a Service Case on page 19
- Contact Quantum Sales on page 19

#### Chatbot

An Al driven Quantum Chatbot is available to ask product support questions, open a service case, or chat with a call center agent. Locate the Q box on the bottom right of a Quantum web page, such as <a href="https://www.quantum.com/en/service-support/">https://www.quantum.com/en/service-support/</a>.

1 Note: Some ad blockers might interfere.

### Open a Service Case


Use any of the following methods to open a service case:

- Al driven Quantum Chatbot. Locate the Q box on the bottom right of a Quantum web page.
- Visit the <u>MyQuantum</u> portal (for more information, see <u>Use MyQuantum Service Delivery Platform on</u> the next page).
  - 1 Note: The MyQuantum portal is the most efficient and preferred method to open a service case.
- Visit the Service & Support page.
  - Note: You can also access other Support related services.
- Call Quantum Support (see Service & Support).

## Use MyQuantum Service Delivery Platform

MyQuantum is a single portal for everything Quantum. You can view assets, open service cases, receive real-time updates, and search the Knowledge Base and documentation, all through a secure, online portal.

- 1. Create an account and log in to the MyQuantum Service Delivery Platform.
- 2. Register a product on MyQuantum.



Request site access to the Cloud-Based Analytics (CBA) monitoring portal and follow the instructions
to set up product(s) to connect to CBA. You can use CBA to monitor Quantum products remotely,
from a single dashboard, and Quantum Support can use it to help troubleshoot products more
efficiently.

## Use Cloud Based Analytics (CBA)

Quantum products are equipped with a Cloud Based Analytics (CBA) agent that can provide log files and snapshots to Quantum CBA servers that are running in the cloud.

CBA enables Quantum systems to collect data regarding system and environment performance. The collected data is bundled and uploaded to the remote CBA server for analysis. You can access Quantum system performance and health results on the CBA dashboard (at <a href="https://insight.quantum.com">https://insight.quantum.com</a>) or through the MyQuantum Service Delivery Platform.

The CBA dashboard displays the analytic results of the uploaded CBA data using flexible charting tools, along with an overall health score of each Quantum system configured for the CBA account.

Refer to product documentation for product-specific information related to CBA.

Refer to the Quantum CBA website for general information about CBA.

## **Escalate a Service Case**

To escalate a service case, follow the process documented here: <a href="https://www.quantum.com/en/service-support/resources/escalation/">https://www.quantum.com/en/service-support/resources/escalation/</a>

### **Contact Quantum Sales**

https://www.quantum.com/en/company/contact-us/